

Never Soak your wallpaper in the water tray, bathtub or closest pond! You only want to run the paper through the water long enough to activate the adhesive on the back if it is pre-pasted.



Preparation is key! Always prep your walls for wallpaper using wallpaper sizing prior to installation. Sizing seals the wall acting as a buffer zone between the wall and wallpaper allowing for better adhesion and strip ability later.



GTK! (Good to Know)

Stripping wallpaper can be as dirty a job as the word itself. Be patient and use a good wallpaper remover. Not allowing sufficient time for the remover to work will only lead to more work for you in the end. We know it is not a fun job but find someone you can have fun with to help pass the time.



VERY Important!

**PREP.
PREP.
PREP.
PREP.....**

Supply List:

- Tape Measure
- Level
- Pencil
- Sponge
- Bucket
- Screw driver
- Snap knife
- Joint knife
- Smoothing tool
- Plumb bob
- Trash bag
- Primer

